

DrainStik™ Installation Requirements

1. The DrainStik™ must be mounted vertically
2. The end of the DrainStik™ must be mounted at least 10mm above the top of the 'U-bend'
3. The top of the DrainStik™ body must be mounted below the drip tray
4. Remove pipe insulation down to the level of the end of the DrainStik™ or use the silicon hose provided

