


13. EXPLODED VIEWS AND PARTS LIST

High Wall Type




CAUTION

For orders of the service parts for High Wall type air conditioners, please check the service parts on Web site of [TOSHIBA CARRIER (THAILAND) CO., Ltd.], and then place an order for parts to (TOSHIBA CARRIER (THAILAND) CO., Ltd.).

Location No.	Part No.	Description	Location No.	Part No.	Description
201	43T00770	FRONT PANEL ASSY	223	43T19333	HOLDER, SENSOR
202	43T00771	CAP SCREW ASSY	224	43T49381	PIPE, SHIELD
203	43T09571	GRILLE OF AIR INLET ASSY	225	43T49383	SEAL, FRONT
204	43T80356	AIR FILTER	226	43T49384	SEAL, UP
205	43T03416	BACK BODY ASSY	227	43T49043	HOLDER, PIPE
206	43T22361	VERTICAL LOUVER ASSY	228	43T49382	PIPE FIXTURE
208	4302C106	MOTOR-LOUVER	229	43T82345	PLATE, INSTALLATION ASSY
209	43T72349	DRAIN PAN ASSY	230	43T62364	TERMINAL COVER ASSY
210	43T2D303	GEAR ASSY	231	43T66434	WIRELESS REMOCO
211	43T22362	HORIZONTAL LOUVER FRONT	232	43T83305	HOLDER, REMOTE CONTROL
212	43T22363	HORIZONTAL LOUVER BACK	233	43T60511	CORD MOTOR LOUVER HR
213	43T70325	DRAIN HOSE ASSY	236	43T91385	PACKING BOX
214	43T79322	DRAIN CAP	237	43T91382	PACKING CUSHION RIGHT
215	43T21492	FAN-MOTOR	238	43T91383	PACKING CUSHION LEFT
216	43T20358	CROSS FLOW FAN ASSY	239	43T91384	PACKING CUSHION CENTER
217	43T39402	BASE BEARING ASSY	240	43T85887	OWNER'S MANUAL (FOR RAV-HM1101KRTP-E)
218	43T22312	BEARING ASSY, MOLD	240	43T85888	OWNER'S MANUAL (FOR RAV-HM1101KRTP-TR)
219	43T39401	MOTOR COVER ASSY	241	43T62365	CLAMP BASE ASSY
220	43T39403	MOTOR BAND BACK			
221	43T39404	MOTOR BAND FRONT			
222	43T44671	REFRIGERATION CYCLE ASSY			

Electric Parts



CAUTION

For orders of the service parts for High Wall type air conditioners, please check the service parts on Web site of [TOSHIBA CARRIER THAILAND CO., Ltd.], and then place an order for parts to (TOSHIBA CARRIER THAILAND CO., Ltd.).

Location No.	Part No.	Description	Location No.	Part No.	Description
401	43TN9669	PC BOARD ASSY (MCC-1696)	405	43T50393	TEMPERATURE SENSOR
402	43T60448	TERMINAL	406	43T50603	TEMPERATURE SENSOR
403	43T60331	TERMINAL, 3P	407	43TN9745	DISPLAY PC BOARD ASSY
404	43T50391	SENSOR; THERMOSTAT	408	43T63356	HOLDER-TA